
Assembly option 2 (arms down)





ATTENTION!

Installation and changing arm direction should be carried out by electrican. Power should be cut off before cleanliness or bulds changing.



or



