

Article 611



Materia prima: Ottone
Funzionamento: Elettrico

Si è elaborato il seguente manuale d'uso allo scopo di fornire le informazioni appropriate per l'installazione e le precauzioni da adottare da parte dell'installatore e dell'utilizzatore.

Il costruttore declina ogni responsabilità in caso di utilizzo dell'apparecchio al di fuori delle istruzioni fornite.

Il cavo d'alimentazione e' collegato all'apparecchio con un collegamento **di tipo Z**, quindi non puo' in alcun modo e per nessun motivo essere sostituito in caso di danneggiamento. Un'operazione di questo tipo renderebbe l'apparecchio pericoloso e farebbe decadere ogni responsabilita' da parte del costruttore.

ATTENZIONE: Questo apparecchio può essere utilizzato solo per supporto di asciugamani o simili. L'apparecchio nel suo normale utilizzo non deve essere caricato con un peso superiore a **5Kg**

Utilizzare solo le viti e i tasselli in dotazione o sostituirli con altre di uguali o maggiori caratteristiche di tenuta meccanica

GRADO DI PROTEZIONE: Apparecchio protetto contro gli spruzzi IPX4.

IMPORTANTE:
IL COLLEGAMENTO ELETTRICO TRA L'APPARECCHIO E LA RETE DEVE ESSERE ESEGUITO DA PERSONALE QUALIFICATO E CON LA RETE ELETTRICA DISATTIVATA

CONTENUTO DELLA CONFEZIONE : (vedi immagine 1)

- (4) Tasselli per fissaggio a muro
- (4) Viti per tasselli
- (1) Manuale d'uso e istruzioni

INSTALLAZIONE: (vedi disegno 2)

Rimuovere lo scaldasalviette e i suoi componenti dall'imballo

Appoggiare l'articolo al muro, e segnare la posizione per eseguire i 4 fori. Inserire i 4 tasselli nel muro ed avvitare la piastra di sostegno dello scaldasalviette.

Solo dopo aver eseguito questa operazioni potrete riattivare il collegamento alla rete elettrica e verificare il corretto funzionamento della scaldasalviette.

La ditta declina ogni responsabilità nel caso di montaggio non corretto.

ATTENZIONE:

Qualora ci sia una fuoriuscita di liquido antigelo dagli scaldasalviette assicurarsi di evitare il contatto con gli occhi, evitare inalazione, evitare ingestione e contatto con la pelle

Raw material : Brass
Operation: Electrical

The following manual has been elaborated in order to supply all the useful information for a correct installation together with the precautions to adopt both from installer and users. **Manufacturer declines every responsibility in case of different uses from these instructions.**

The heated towel rails is connected to the mains with a **Z type** connection, and consequently it cannot be substituted in any case of damage. Such an action would make the item dangerous and free the producer from every responsibility.

ATTENTION :This item can be only used as holder for towels and similar garments.

This item, in normal use, cannot be loaded with more than **5 Kg.** weight.

Please, only use provided screws and dowels or replace them with other ones equivalent or greater in mechanical characteristics.

PROTECTION DEGREE: Squirts resistant IPX4.

IMPORTANT:
THE ELECTRICAL CONNECTION BETWEEN ITEM AND MAINS MUST BE EXECUTED BY QUALIFIED STAFF AND AFTER TURNING OFF ELECTRICITY AT THE MAIN PANEL.

PACKING CONTENTS : (see image 1)

- (4) Dowel for wall
- (4) Screw for dowel
- (1) Instruction & Operation Manual

INSTALLATION: (see design 2)

Take out the heated towel rail and its components from the package.

To mount the heated towel rails to the wall, and to mark the position and make the 4 holes in correspondence.

To insert the 4 dowels in the wall and to screw the anchor plate of support of the heated towel rails.

Only after finishing this action, you can turn the power on and verify the heated towel rails works correctly.

Our Company refuses any responsibility in the case the assembly doesn't respect the above mentioned instruction.


WARNING:

Whether a leakage of antifreeze liquid occurs from our electrical towel heaters, take care not to permit any contact with eyes and skin and avoid inhalation or ingestion

1)



2)



Norme CEI Standards CEI Normes CEI CEI Normen Normen CEI Normas CEI Normas CEI	→ → → → → → → →	Zona di Installazione Zone of Installation Zone d' Installation Installationsort Zone van Installatie Zona de Instalación Zona de Instalação
--	-----------------	---

ZONA ZONE		
0	NO - NON - NEIN NEE - NAO - NEJ	NO - NON - NEIN NEE - NAO - NEJ
1	NO - NON - NEIN NEE - NAO - NEJ	NO - NON - NEIN NEE - NAO - NEJ
2	★ SI - YES - OUI JA - SIM	NO - NON - NEIN NEE - NAO - NEJ
3	★ SI - YES - OUI JA - SIM	★ SI - YES - OUI JA - SIM

★ Solo se protetti da interruttore differenziale con IΔN ≤ 30 mA
★ Only if shielded by a safety switch IΔN ≤ 30 mA
★ Seulement si pourvus de disjoncteur général avec IΔN ≤ 30 mA
★ Nur in Verbindung mit Sicherheitsschalter IΔN ≤ 30 mA
★ Alleen met een automatische differentieelschakelaar met IΔN ≤ 30 mA
★ Sólo si están protegidos por el interruptor diferencial IΔN ≤ 30 mA
★ Apenas se protegidos por interruptor diferencial com IΔN ≤ 30 mA

ATTENZIONE: NON smaltire lo scaldasalviette come normale rifiuto urbano, ma effettuare una raccolta separata e uno smaltimento in apposito centro attrezzato.
WARNING: DO NOT get rid of this item as urban waste, but swallow it separately or by properly equipped institutes.