

AVVERTENZE PER L'INSTALLAZIONE

Avviso: Una errata installazione o danno possono compromettere il funzionamento del tubo o della connessione, con conseguente flusso incontrollato di acqua. Ciò potrebbe causare gravi e costose inondazioni, in particolare se la fuoriuscita non viene rilevata e fermata prontamente.

	PLATINOX® NEOFLEX®SPX TOILET HOSES PARINOX® FLEXCORE®	SUPERCOATING	LAVINOX MIXINOX NYLONFLEX	AVC AVT SAEPAR	ST NW VT	SICURGAS®NG DN8 - DN13	VIX PGN	SIM-G SUPERGAS by PARIGI®	GD RC	TAM	CRG	KITCHEN-FLEX SILICONE PRO GLIDEFLEX®	CHROMALUX® METALLIC SMOOTH SPIRAL SUPREME
	Prima di montare il tubo, verificare che entrambi i raccordi siano stati bloccati correttamente.	•	•	•	•	•					•	•	•
	È necessario mantenere sotto ai raccordi un tratto dritto, pari a 1,5 volte il diametro esterno del tubo.	•	•	•	•	•	•				•	•	•
	Non piegare la parte flessibile con raggi di curvatura inferiori a quanto indicato sulla scheda tecnica del prodotto.	•	•	•	•	•	•	•	•	•	•	•	•
	Non installare il tubo con la parte flessibile in tensione.	•	•	•	•	•	•	•	•	•	•	•	•
	Non installare il tubo con la parte flessibile in torsione.	•	•	•	•	•	•	•	•	•	•	•	•
	I collegamenti dell'apparecchio di cottura deve essere dotato di messa a terra efficiente.							•					
	Montare i raccordi MDB-MDG su tubetti di rame aventi spessore di parete non inferiore a mm. 0,75. Eseguire il serraggio dei raccordi MDG-MDB con forza compresa tra 25 e 35 Nw.	•	•								•	•	•
	Non installare i flessibili AVC con treccia zincata in ambienti umidi. I tubi AVC con treccia zincata non devono mai essere installati con rivestimento isolante.			•									
	Al termine di ogni lavaggio il rubinetto deve essere chiuso per non lasciare il tubo di carico in pressione.		•										
	Protezione danni: Proteggere il tubo da eventuali danni: - Evitare il contatto con il calore estremo (oltre 150 ° F / 65,6 ° C) - Evitare il contatto con prodotti chimici per la casa, come la candeggina - Non utilizzare detergenti chimici o abrasivi - Pulire solo con un panno umido	•	•	•	•	•	•	•	•	•	•	•	•
	Il flessibile GS deve essere installato dopo il limitatore di portata, su impianti domestici a gas liquido posti all'esterno delle abitazioni.												
	Periodicamente verificare che non sia stata superata la scadenza di 5 anni; non appaiano tracce di bruciature/surriscaldamento sulla superficie del tubo; che il materiale del tubo non appaia deteriorato, invecchiato o troppo indurito.												
	Per l'installazione dei raccordi si raccomanda l'utilizzo di chiavi fisse di misura adeguata alla dimensione del raccordo.	•	•	•	•	•	•	•	•	•	•	•	•
	Evitare di colpire il tubo con oggetti taglienti o appuntiti.	•	•	•	•	•	•	•	•	•	•	•	•
	Non collegare mai due o più tubi flessibili fra loro.	•	•	•	•	•	•	•	•	•	•	•	•
	I tubi flessibili devono essere installati in modo da rendere possibile in qualsiasi momento l'ispezione e l'eventuale sostituzione; in tutte le installazioni non "a vista" (es. cassette WC, vasche idromassaggio), è necessaria la presenza di un vano di ispezione che consenta l'eventuale smontaggio del tubo flessibile.	•	•	•	•	•	•	•	•	•	•	•	•
	Controllare periodicamente. Sostituire il tubo flessibile se: - perde - vi sono ruggine, segni di corrosione o segni di danneggiamenti - l'apparecchio è stato sostituito.	•	•	•	•	•	•	•	•	•	•	•	•
	Aprire l'acqua e verificare eventuali perdite. Se vi è una perdita: stringere di un ulteriore 1/8 di giro dopo essersi accertati che la guarnizione sia ben compressa. NON STRINGERE ECCESSIVAMENTE. Un ulteriore serraggio non aiuterà e può causare danni. Se la perdita continua, chiudere l'acqua e verificare la guarnizione del tubo e se la filettatura è danneggiata o sporca. Se la connessione perde ancora, sostituire/cambiare il flessibile e verificare se l'impianto funziona correttamente.	•	•	•	•		•			•	•	•	•

NEOPERL®

flow, stop and go®

PARIGI®
NPI Italia Srl | A NEOPERL Company

www.npiitalia.com

INSTRUCTIONS FOR THE INSTALLATION

Notice: Improper installation or damage can lead to failure of the hose or connection, resulting in uncontrolled flow of water. This could cause extensive and costly flooding and water damage, particularly if the leaking is not detected and stopped promptly.

		PLATINOX® NEOFLEX®SPX TOILET HOSES PARINOX® FLEXCORE®	SUPERCOATING	LAVINOX MIXINOX NYLONFLEX	AVC AVT SAEPAR	ST NW VT	SICURGAS NG	VIX PGN	SIM-G SUPERGAS by PARIGI®	GD RC	TAM	CRG	KITCHEN-FLEX SILICONE PRO GLIDEFLEX®	CHROMALUX® METALLIC SMOOTH SPIRAL SUPREME
	Before assembling the hose, check if both fittings have been clamped correctly.	•	•	•	•	•	•					•	•	•
	Hoses must have, under the fittings, a straight length that corresponds to once and a half the outside diameter of the hose.	•	•	•	•	•	•	•				•	•	•
	Hoses are not to be bent with inferior bending radius than the ones showed in the technical data sheet.	•	•	•	•	•	•	•	•	•	•	•	•	•
	Hoses must be tightened, during the assembling, without any tension.	•	•	•	•	•	•	•	•	•	•	•	•	•
	Hoses must be tightened, during the assembling, without any twist.	•	•	•	•	•	•	•	•	•	•	•	•	•
	The connection of the cooker has to be provided with an efficient earthing.								•					
	MDG-MDB fittings have to be assembled on copper pipes having a minimum thickness of mm.0,75. The MDG-MDB fittings have to be tightened with a clamping force between 25 and 35 Nw.	•	•									•	•	•
	Do not install AVC-Z hoses with galvanised steel brading in damp rooms. The insulation coating can never be used on AVC-Z hoses with galvanised steel brading.				•									
	At the end of each washing, the water supply tap must be closed otherwise the hoses will remain under pressure.			•										
	Damage protection: Protect the hose from damage: - Do not allow contact with extreme heat (over 150°F / 65.6°C) - Do not allow contact with household chemicals, such as bleach - Do not use chemical cleaners or abrasives – clean only with a wet cloth	•	•	•	•	•	•	•	•	•	•	•	•	•
	GS hose must be installed after the pressure limiting device, on GPL domestic plants placed outside buildings.													
	Periodically it must be verified that the 5 years expiry date is not over, that the hose surface does not show burning/overheating traces, that the hose material does not look deteriorated, aged or too much hardened.													
	For the installation of the fittings it is recommended the use of wrenches whose size is adequate for the dimension of the fitting.	•	•	•	•	•	•	•	•	•	•	•	•	•
	Avoid striking the hose with cutting or sharpened objects.	•	•	•	•	•	•	•	•	•	•	•	•	•
	Never connect two or more hoses among themselves.	•	•	•	•	•	•	•	•	•	•	•	•	•
	Flexible hoses shall be installed in such a way as to make inspection and the eventual replacement possible at any time; particularly in built-in installations (i.e. in toilet flushing cisterns, in whirlpool bath tubs and in shower walls), it is necessary an inspection point allowing the eventual disassembly of the flexible hose.	•	•	•	•	•	•	•	•	•	•	•	•	•
	Inspect periodically. Replace the hose if: - it leaks - there is rust, corrosion or any sign of damage - the fixture is replaced.	•	•	•	•	•	•	•	•	•	•	•	•	•
	Turn on water and check for leaks. In case of leakage: tighten another 1/8 turn after having checked that the washer is properly seated and compressed. DO NOT OVERTIGHTEN. Additional tightening will not help and can cause damage. If leak continues, shut off water and check hose washer and threads for damage or debris. If connection still leaks, replace/exchange hoses or fixture as appropriate.	•	•	•	•			•			•	•	•	•

NEOPERL®

flow, stop and go®

PARIGI®
NPI Italia Srl | A NEOPERL Company

www.npiitalia.com