



Series 8 Bifold door/Shower wall


Bifold Door



Shower wall



Corner Door



NOTE: When the products is being used as a Bifold in a recess or with a side panel it can be used with or without a shower tray as it come with a bottom optional frame section. We do not recommend using the door on a shower tray when used as a shower wall or corner door as water tightness cannot be guaranteed as there is no bottom frame available.

IMPORTANT

Thank you for choosing Merlyn. Please familiarise yourself with the fitting instructions before commencing fitting.

1. Check that you have the tools required.
2. Check that the installation site is compatible with size of door supplied
3. Check all the enclosure components.
4. Check that the installation kit is complete

DO NOT attempt to install the product unless you can tick ALL 4 boxes as satisfactory.

The wall plugs supplied with the installation kit are for use in solid walls. Hollow or 'stud-partition' walls will require alternative fixings. Please consult a hard ware supplier for the correct type.

It may also be necessary to consult your tiling supplier about the correct method for drilling your tiles.

USE SAFETY EYEWEAR WHEN DRILLING

Any parts missing or damaged must be reported to your supplier within 5 days of purchase. Inspect shower enclosure before fitting as no claims will be acceptable after product has been installed.

Adjustment when used as Bifold door in recess


Size	Adjustment	Opening space
760	720-750	520
800	760-790	560
900	860-890	670
1000	960-990	780


Adjustment when used as Shower wall

Size	Adjustment
760	680-700
800	720-740
900	820-840
1000	920-940


Adjustment when used as Corner door

Size	Adjustment 'X'
760x760	715-735
800x800	755-775
900x900	855-875
1000x1000	955-975





No	Description	QTY	Part No.	No.	Description	QTY	Part No.
1	Closing post cover cap L/R	2	M7120	13	Flat head screw ST4x30	8	2YS51
2	Magnet profile universal cover cap	1	M7121	14	Handle	1	M7116
3	Magnet seal	1	M7111	15	Bottom seal	2	M7107/M7108 /M7109
4	Moving panel A	1	A	16	Luna rail end cap hinged side L/R	2	M7118
5	Moving door upright water seal	1	M7110	17	Luna rail	1	M7103
6	Hinge	2	M7114	18	Luna rail end cap closing side L/R	2	M7119
7	Cover cap for wall profile L/R	2	M7017	19	Magnet profile	1	M7105
8	Moving panel B	1	B	20	Screw cover cap clip	3	M7124
9	Cover strip	1	M7104	21	Screw ST4x12	6	A2401201
10	Wall profile	1	M7100	22	Screw cover cap	3	M7123
11	Cover strip clip	5	M7009	23	Magnet wall profile	1	M7106
12	Φ6x30 wall plug	8	B08070				



Fixing kit components

4x30mm



2SY51x8

4x12mm



A2401201x6




B08070x8




M7124x3



M7123x3



M7020
X1



Ø3mm


B08092x1



M7017x2




M7120x2



M7119x2



M7121x1



M7118x2



M7116x1







B08068x1



M7115x8


Tools required




6mm



PH2



PROCEDURE





TRAY MUST BE LEVEL IN ALL DIRECTIONS!

Ensure the shower tray is level in all directions and is properly sealed to the wall. The wall must be tiled down to the top edge of the tray. **Do not angle out bottom tile.**

TRAY MUST BE SEALED FULLY AROUND WHERE THE TRAY MEETS THE WALL.

Note: Determine the handing, note that the wall profile is only fitted to the hinged side.




Determine distance from edge of tray to front of profile.

NOTE: If fitting as corner door please refer to the adjustment table on page 1. We do not recommend fitting the product on a shower trays when used as a showerwall or corner door.

3

The door is set up as left hand, to reverse for right hand follow steps below




First loosen the top bracket and remove the profile and bracket assembly. Then remove parts M7024 & M7025.

Note M7025 with V should always be on the bottom.


LH

RH






A

Remove bracket and profile




B


Remove M7024



F




G




C

Remove M7025



D


Flip the glass panels end over end



E

Fit M7025 (part with V) to the bottom of the profile

4




NOTE: Make sure the cutout in the top and bottom bracket faces in.

Use spacer provided to set the gap under the glass

5

Drill three holes on the inside of the wall profile and fix using screws A2401201




TOP TIP ! Fit seal to side closest to shower head. Bottom of the seal should be flush with the bottom of the glass.

6

Cut excess only from the hinged side of both seals.

End of the bottom seal should be flush with the outside face of the upright seal.


Make sure the angled fin is to the inside




Note: If fitting as a shower wall skip to step 10 for sealing instructions.
If fitting as a corner door skip to step 11.

7


A



For Bifold in recess or with side panel ensure the magnet is 13mm below the glass panel




B



Fit part M7119 to the bottom of the magnet profile assembly.


C




M7020

D

Close door fully, align magnets and mark position the profile on the wall.




Align the Magnet profile to the line and mark hole position




Φ 6mm


F



G




H




INSIDE

I




8







WARNING - The bottom frame can only be used when the product is fitted as a Bifold in a recess or with a side panel. It cannot be used for a showerwall or corner door situation. The bottom profile must be used to ensure water tightness under the moving panel. We cannot guarantee water tightness if this is not used.

9



NOTE: Make sure the handle is fitted with the bump stops facing to the outside.

10




SEALING INSIDE

Seal top to bottom on the **INSIDE** between the wall profile and the wall.

Note: Do not apply sealant on the inside of the tray.

SEALING OUTSIDE

Seal only along bottom on the **OUTSIDE** between glass/rail/profile and the tray and approx 50mm up between the wall profile and the wall. Seal joint between bottom profile and upright profile.



DO NOT USE THE ENCLOSURE FOR 24 HOURS AFTER SEALING

11



Pivoting Side

Cut excess only from the hinged side of both seals.

Central Hinge


End of the bottom seal should be flush with the outside face of the upright seal.

Magnetic Side




NOTE: For a corner door situation, the seal that goes under the magnetic side moving panel and the angled magnets are in a separate box. The seal on the wall side moving panel is still used. Please discard and seal left over from the glass panel boxes

12



NOTE: Make sure the handle is fitted with the bump stops facing to the outside.

13




SEALING INSIDE

Seal top to bottom on the **INSIDE** between the wall profile and the wall.

Note: Do not apply sealant on the inside of the tray.

SEALING OUTSIDE

Seal only along bottom on the **OUTSIDE** between glass/rail/profile and the tray and approx 50mm up between the wall profile and the wall. Seal joint between bottom profile and upright profile.



DO NOT USE THE ENCLOSURE FOR 24 HOURS AFTER SEALING